



HO Scale Detail Kit

CHAIN LINK FENCE

933-3125

Thanks for purchasing this Cornerstone Series® Kit!

Please read all the instructions before starting. All parts are molded in styrene plastic, so use glues and paints that are compatible.

1) For easier construction, paint all parts silver or aluminum (paint sold separately) before beginning assembly. Select a location for the fence and determine the spacing of the poles, starting from a corner — poles are usually no more than 10' (3m) apart, and should be installed with the angled top facing outward. Poles used for gateposts should be spaced 2-3/4" (7cm) apart; gates may be located at the corners or on any side of the enclosure as desired.

2) Drill mounting points for each Pole with a #62 drill bit (sold separately), apply glue and push poles in place down to the bottom collar.

3) Measure the distance between each corner post. Cut two pieces of wire (eight total) to fit between each corner post — wires between access gates only: add 1/16" (1.5mm) to the overall length and bend approximately the last 1/16" (1.5mm) of each wire at a right angle as shown. Align wires below the upper and above the lower collars as shown, and glue in place with cyanoacrylate (CA) type adhesive (sold separately) — wires between access gates only: make sure the bends face upward and extend about 1/16" (1.5mm) beyond the gateposts. Align Hinges on Gates as shown and glue in place. When dry, slip Hinges over mounting wires.

4) Mount the chain link material on a sheet of contact paper (sold separately) and cut into uniform strips, each 15/16" (23.8mm) wide. Starting at a corner, work slowly and carefully align the edge of the material on the edge of the Pole, and glue in place using CA adhesive — a slow-setting formula will give you time to make adjustments. When dry, carefully pull the material taut as far as the next Pole, and apply small amounts of CA along the top and bottom wires. Repeat for each Pole.

