



®

HO Scale Kit **TRACK BUMPERS** 933-3511

Thanks for purchasing this Cornerstone Series® Kit! Please read all instructions before starting. All parts are molded in styrene plastic, so use glues and paints which are compatible.

Before Assembly

Check kit for proper number of parts. Cut and file flash from parts. Sand edges to ensure right angle joints with no gaps between parts.

Assembly

Glue the bumper halves (18, 24) together and then to the base (17). Glue the vertical support (19) to the base and to the top back of the bumper.

Painting

You can paint this kit with brush, spray can or airbrush. Paint after assembly is complete to help cover up any seams. Weathering is optional.

