





4. Glue the pilaster fillers (49) in place on the backs of walls 6 & 7. For proper alignment, glue the rear wall joiners (44) to the backs of walls 10 & 13 and 11 & 13 as shown. Use the front corner joiners (35) to align walls 6 & 7. Glue the wall sections (5,6,7,8,9,10,11,12,13) together and to the base (1). NOTE: Walls 6&7 are interchangeable; you can have the main entrances on the side walls or both entrances on one corner. Glue on the roof (19).



5. Glue the headhouse walls (14,15) together and in place on the main roof. Then glue on the headhouse roof (20).
 6. Glue the water tank supports (16,17) in place on the roof. Next glue the column (30) together and in place on the raised funnel on the roof. Glue the water tank sides (25) together and to the base (18). Glue the tank top (26) on. Then glue the completed water tank on top of the supports, with the column going into the hole in the bottom of the tank base. Cut the ladder (29) in half (approximately 50mm) and glue the bottom half to the raised ridges on part #17. Glue the top half to the base (18) and top (26), in front of the inspection hatch. NOTE: Some tank parts are found on sprue 7003044/H.

7. On the rear wall, glue the loading dock (3) under the freight doors. Glue the railings (45,46) onto the stairs (4) and then glue them in place under the small door on the rear wall.
 8. If you used freight doors on the side walls (step 3), glue the small loading docks (2) in place under the doors.



NOTE: You will not use parts 24,27,28 found on the water tank sprue 7003044/H.

DECALING

1. After cutting out the decal, dip in water for 10 seconds, remove and let stand for 1 minute. Slide decal onto surface, position and then blot off any excess water.
2. Lightly brush Micro Sol® on top. This will soften the decal allowing it to conform to irregular surfaces. DO NOT TOUCH DECAL while wet!
3. When the decal is thoroughly dry, check for any trapped air bubbles. Prick them with the point of a small pin or hobby knife blade and apply more Micro Sol®.